

CASK DISPENSE EQUIPMENT

OUR POLICY

Equipment installed to maintain a dispense temperature of 11-13°C.

WHY WE DO IT

Cooling equipment installed for cask ales will deliver fresh tasting beer, minimise wastage from fobbing or flat dispense, customer complaints and beer returns to the brewery

DO

- ✓ Install all required equipment wherever possible.
- ✓ Check water levels on cask ale coolers and top up if required at least weekly.
- ✓ Check cask ale is dispensing between 11-13°C at least weekly.
- ✓ Call Quality and Dispense Services if dispense temperature is always outside 11-13°C.

DON'T

- ✗ Turn off cask ale coolers.

CASK DISPENSE EQUIPMENT PROCESS

Wherever possible, cask ales should be installed with the following equipment in place:

- ◆ Cask ale cooler with the thermostat set to dispense cask ales between 11-13°C.
- ◆ Designated cask ale python.
- ◆ Beer engines with water jacketed cylinders.
- ◆ Pipework to be configured in accordance with Quality and Dispense Services installation standards manual.

GOT A PROBLEM WITH BEER QUALITY?
VISIT: WWW.BEER-GENIUS.CO.UK

